

DRIVEABLE BASE INSTALLATION INSTRUCTIONS

Part #105NS



1. Drive the base in the ground approximately 2". Remove the base and dislodge the dirt from the bottom.
2. Using a drivecap and a sledhammer, drive the base into the ground until 1" is left showing. You can also use a signpost driver with a driver cap. Do not use a sledgehammer directly on the base or it may bend and the unit will not fit into the base.
3. Make sure the unit you are installing is facing traffic and attach the unit with the two (2) 3/4" hex screws that are included with the base.

IMPACT recovery
S Y S T E M S

— — — — —
" Impacting Today's Roads for a Safer Tomorrow"

4955 Stout Dr.
San Antonio, TX 78219
210-736-4477
800-736-5256
Fax 210-734-6448