

Maintenance


The reactive spring system of the Sentinel BCB product requires no maintenance.

Cleaning

Posts and railing may be cleaned periodically with a gentle cleaning solution.

Recommended Solutions:

- Sky Light™ by Ramsey
- Simple Green®



Inspection

Periodically inspect the posts and railing system for obvious damage due to excessive impacts or vandalism.

Post Replacement

- Remove the two security screws located at the bottom of the post.
- Replace the post, align the screw holes, and re-tighten the screws into the existing holes in the spring unit.

Spring Replacement

- Remove the four security button screws holding the spring to the railing
- Replace the post and re-tighten the hex screws into the existing holes in the spring unit.

Railing anchors may come loose over time with excessive vibration or impacts. Inspect periodically and re-tighten with an impact wrench. Inspect at a minimum of annually, but more often if conditions warrant.

