




1. INSTALL SURFACE MOUNT BASE USING ANCHOR KIT PROVIDED. SEE DIRECTIONS INSIDE KIT. "TRAFFIC" MARKING ON BASE SHOULD BE ORIENTED TOWARD EXPECTED TRAFFIC. ATTACH TO FLAT CONCRETE OR ASPHALT.
2. ATTACH LOWER PORTION OF SIGN POST TO BASE USING THE FOUR CAP SCREWS AND WASHERS PROVIDED IN BASE. NOTE THE ORIENTATION OF SMALL HOLE IN SIGN POST BASE SPRING UNIT.
3. INSERT TOP PORTION OF ALUMINUM SIGN POST TO LOWER PORTION OVER EXTENSION PIECES AND SECURE USING PHILLIPS PAN HEAD SCREWS PROVIDED.
4. ATTACH SIGN BRACKETS TO SIGN FACE THROUGH TWO HOLES IN SIGN FACE. FULLY TIGHTEN FRONT BOLT. BE SURE TO KEEP THE BRACKETS CLAMP HOLES ALIGNED VERTICALLY.
5. LOOSEN THE SIGN BRACKET CLAMPS AND SLIDE THE BRACKETS OVER THE SIGN POST. ONCE IN DESIRED POSITION, TIGHTEN CLAMPING HEX BOLTS.

NOTE  
SUPPORTS ONE ALUMINUM SIGN UP TO 12"x15"  
OR ONE PLASTIC SIGN UP TO 18"x24".

CALL CUSTOMER SERVICE AT 1-800-736-5256  
IF YOU HAVE ANY ISSUES. WE'RE HAPPY TO  
HELP.



Detail B



Detail A



CONFIDENTIAL & PROPRIETARY

The drawing on this print and the information therewith are property of Impact Recovery Systems, Inc., and shall not be used or discussed in whole or in part without the consent of Impact Recovery Systems, Inc.

4955 STOUT DR. · SAN ANTONIO, TX 78219 · (800) 736-5256

SIZE  
**A**

SCALE

PART NO.  
STRB-78xF-FB

DWG.  
STA-RITE BOLLARD  
ENHANCED SIGN POST

IMPACT RECOVERY

DATE 20-JUN-2018

REV  
1.1